


S7X Operation Manual

1.Outlook



2.Functions

FUNCTIONS	STATUS	BUTTON	HOW TO USE	VOICE
LED ON	POWER ON	VOLUME - & FUNCTION	PRESS ONCE	
POWER ON	POWER OFF	FUNCTION	PRESS AND HOLD 5S (WHILE POWER ON DEVICE INTO PAIRING MODE DIRECTLY)	Power ON
POWER OFF	POWER ON	FUNCTION	PRESS AND HOLD 5S	Power OFF
PHONE CALL				
PICK UP	INCOMING CALL	FUNCTION	PRESS ONCE	
HANG UP	DURING CALL	FUNCTION	PRESS ONCE	
REJECT	INCOMING CALL	FUNCTION	PRESS AND HOLD 2S	
REDIAL	STAND BY	FUNCTION	PRESS TWICE	
VOLUME UP	DURING CALL	VOLUME +	PRESS ONCE	BEEP
VOLUME DOWN	DURING CALL	VOLUME -	PRESS ONCE	BEEP
VOICE COMMAND	STAND BY	VOLUME + & -	PRESS ONCE AT THE SAME TIME	
Manual/Auto Switch:	NOT CONNECTED	VOLUME + & -	PRESS ONCE AT THE SAME TIME	BEEP
MUSIC PLAY				
PLAY	STAND BY	FUNCTION	PRESS ONCE	
PAUSE	MUSIC PLAYING	FUNCTION	PRESS ONCE	
VOLUME UP	MUSIC PLAYING	VOLUME +	PRESS ONCE	BEEP
VOLUME DOWN	MUSIC PLAYING	VOLUME -	PRESS ONCE	BEEP
PREVIOUS	MUSIC PLAYING	VOLUME -	PRESS AND HOLD 2S	
NEXT	MUSIC PLAYING	VOLUME +	PRESS AND HOLD 2S	